

Chapter 1: Introduction

Congratulations on purchasing Metrosonics aq Series Indoor Air Quality Monitor. The aq Series consists of the IAQ Monitor Hand-Held Indoor Air Quality Monitor and the aq-5001 Portable Indoor Air Quality Monitor. As you will see in this instruction manual, you can easily convert the aq-5001 into the IAQ Monitor Hand-Held version as the need arises.

Metrosonics aq Series IAQ Monitors, measure, display and record data on up to five channels. Each channel permits monitoring one of the following: carbon dioxide, temperature, relative humidity, toxic gas, and a linear input. The carbon dioxide, temperature and relative humidity inputs are built into the monitoring unit. The toxic gas input allows you to use Metrosonics optional toxic gas sensors to measure any of the following gases: carbon monoxide, hydrogen sulfide, sulfur dioxide, chlorine, nitrogen dioxide, nitric oxide, oxygen, hydrogen cyanide, ammonia and ethylene oxide. The linear input provides the flexibility to attach your own input source and monitor additional pollutants.

All chosen channels are measured simultaneously, allowing information to be correlated and compared.

ms-5000W Windows-based Metrosoft Software is available for use with the aq Series Monitors. This software is totally menu driven and easy to use. It allows programming your air quality monitor within seconds, creating graphs and reports, performing database searches and more!

IMPORTANT!

Register your IAQ Monitor/aq-5001 Indoor Air Quality Monitor NOW. Simply fill out and mail the enclosed warranty card.

www.metrosonics.com

Before You Begin

Check to Make Sure You have the Right Hardware

The following is a list of requirements for any computer or printer to work with your IAQ Monitor:

- Serial RS-232 communications using at least the transmit (TX pin 2), receive (RX pin 3) and common ground (GND pin 7) lines
- Accept XON/XOFF software handshaking, also known as DC1/DC3 or CtrlS/CtrlQ
- Accept a baud rate of 1200, 2400, 4800, 9600, 19200 or 38400 baud
- Data format of 1 start bit, 8 data bits, 1 stop bit and no parity
- Accept the standard ASCII character set
- Support 80 column printouts

Using AC Power and the Internal Battery

The aq Series Monitors come with an AC power adapter and a set of four AA alkaline batteries. An optional sealed rechargeable battery pack is also available. Call Metrosonics Sales Department at 716-427-7402 for more information on this option.

Either AC power or internal batteries can be used to supply power to the IAQ Monitor during tests; whichever best suits your needs. The batteries are convenient for walkthrough surveys, while AC power offers longer monitoring sessions. In addition to powering the IAQ Monitor, the internal batteries also provide a back up power source for programming and data retention.

The batteries **MUST** have a voltage of greater than 4.1 volts to properly operate the IAQ Monitor. If the battery drops below 4.1 volts while the IAQ Monitor is operating, the IAQ Monitor will automatically shut down and save the data already in memory and the programming information for 30 days. This allows plenty of time for you to change or recharge the batteries.

You can check the current battery voltage by turning on the IAQ Monitor and pressing the arrow key (see "Reviewing the IAQ Monitor's Status" in Chapter 4).

NOTE: The IAQ Monitor draws power from the internal batteries in order to maintain the clock and store programming information in memory. If the IAQ Monitor will not be used for an extended period of time, the batteries should be removed. New batteries should be installed when the IAQ Monitor is used again.

Replacing the Internal AA Batteries

The procedure for replacing the AA batteries is very simple and can easily be performed within seconds. The IAQ Monitor will maintain its programming information and logged data during battery replacement, provided that the replacement procedure DOES NOT take more than 2 minutes.

The IAQ Monitor **MUST** be turned off before removing the bottom end-cap. If the IAQ Monitor is turned on when the battery is removed, all programming and logged data will be lost.

Follow these instructions to replace the AA batteries in the IAQ Monitor (be sure you have fresh batteries ready before beginning this procedure):

1. Turn the IAQ Monitor off by pressing the ON/OFF button.
2. Use a phillips-head screwdriver to loosen the screw on the battery door, located on the bottom end-cap of the IAQ Monitor, and then remove the battery door.
3. Tilt the IAQ Monitor towards you and tap it on your hand so the old batteries slide out.
4. Slide the fresh batteries into the battery compartment with the + and - terminals matching the diagram on the back label of the unit. **The batteries must be installed in less than 2 minutes to prevent possible data loss.**
5. Replace the battery door and tighten the screw so that it fits securely and the opening is sealed.

Optional Battery Pack

These instructions are only applicable if you have purchased the optional NIMH Battery Pack (part #ba-7400).

Installing the Battery Pack

Follow these instructions to install the optional battery pack in the IAQ Monitor (be sure you have the battery pack handy before beginning this procedure):

1. Turn the IAQ Monitor off by pressing the ON/OFF button.
2. Use a phillips-head screwdriver to loosen the screw on the battery door, located on the bottom end-cap of the IAQ Monitor, and then remove the battery door.
3. Tilt the IAQ Monitor towards you and tap it on your hand so the old batteries/battery pack slide out.
4. Slide the battery pack into the battery compartment. With the front panel on the IAQ Monitor facing the ceiling, insert the battery pack so that the contacts face down. The label on the battery pack has an arrow that indicates which end goes in first. **The battery pack must be installed in less than 2 minutes to prevent possible data loss.**
5. Replace the battery door and tighten the screw so that it fits securely and the opening is sealed.

Charging the Battery Pack

If you will be using the battery pack as your power source, we recommend fully charging it before you begin recording data.

Charging the battery pack requires a Charger/Manager (part # bcm-7400) and an AC Charger (part #bc-7400-1 or bc-7400-2).

To recharge the battery pack:

1. Turn the IAQ Monitor off by pressing the ON/OFF button.
-

2. Metrosonics offers two different AC chargers for the battery pack. Follow the instructions for the AC charger that you have:

bc-7400-1: Plug the bc-7400-1 AC charger into a 120 VAC, 50 or 60 hz, power source. Next, plug the AC charger into the dc input connector of the Charger/Manager.

bc-7400-2: Plug the power cord into a power source with the voltage between 100 and 240 VAC, 50 or 60 hz, and then plug the other end of the power cord into the bc-7400-2 AC charger. Next, plug the AC charger into the dc input connector of the Charger/Manager.

3. Plug the 5-pin connector of the Charger/Manager into the battery charger input on the top end-cap of the IAQ Monitor (see the IAQ Monitor instrument diagram at the beginning of Chapter 4 to locate the 5-pin connector). A few seconds later, the LED on the Charger/Manager will turn red, indicating a high rate charging condition.
4. A fully discharged battery pack will take at least 3 hours to completely recharge. Less discharged packs will recharge sooner. Upon completion of the high rate charge, the Charger/Manager's LED will turn green. Leave the Charger/Manager connected for 30 minutes after the LED turns green and the battery pack will be completely recharged.
5. You can now disconnect the AC charger from the IAQ Monitor.

NOTE: While recharging the battery pack, the LED on the Charger/Manager will indicate problems as follows:

1. A flashing red LED on the Charger/Manager indicates:
 - a. A low voltage from the AC charger. This can be caused by either a power source problem or a bad AC charger.
 - b. The battery pack has shorted batteries.
2. A yellow LED on the Charger/Manager indicates the battery pack is outside of its temperature range of -10 to +35°C (+14 to +95°F). Charging will not continue until the ambient temperature is within this range.

NOTE: The battery pack is not damaged by leaving the Charger/Manager connected after the LED turns green.

NOTE: The battery pack should not be allowed to become fully discharged or left in a "low charge" state for an extended period of time. If left unused, the battery should be recharged every three months and before using the IAQ Monitor.

Setting The Real Time Clock

If you want the IAQ Monitor to record in real time, you must use ms-5000W Metrosoft to set the real time clock before you begin recording.

ms-5000W Metrosoft automatically sets the real time clock of the IAQ Monitor to the current time at your computer when you program the IAQ Monitor for a test (see the on-line help in ms-5000W Metrosoft for more information).

Selecting Channels

The IAQ Monitor comes with the following 5 channels:

1. Carbon Dioxide (CO₂)
2. Temperature
3. Relative Humidity
4. Toxic Gas
5. Linear Input

You can record data on any or all of these channels. The IAQ Monitor comes factory programmed with the CO₂, temperature and humidity channels turned on (they will be recorded), and the toxic gas and linear channels turned off (they will not be recorded).

The present readings for the CO₂, temperature and humidity channels are always displayed, even if you are not recording them.

Readings from the toxic gas channel will only appear on the display if a toxic gas sensor is plugged in when the IAQ Monitor is turned on. If you want to record data from the toxic channel, you must use ms-5000W Metrosoft to program the IAQ Monitor to do so (see the on-line help in ms-5000W for more information).

Readings from the linear channel will only appear on the display if the IAQ Monitor is programmed to record data on that channel.

To change which channels will be recorded, or make other programming choices, you must use ms-5000W Metrosoft to make your selections and then reprogram the IAQ Monitor (see the on-line help in ms-5000W Metrosoft for more information).

Default Recorder Setup

The IAQ Monitor comes factory programmed for common test conditions, allowing immediate operation. All setup choices may be changed using ms-5000W Metrosoft (see the on-line help in ms-5000W Metrosoft for more information).

The following lists default settings programmed at the factory:

- CO₂ Range: 5000 ppm
- Instrument Mode: Survey
- Storage Period: 1 second sample
- Memory Mode: Stop when Full
- Display Overall Statistics: Brief (displays all tests)
- Temperature Scale: °F
- Display Backlight: Enabled
- Secure Code: 1-2-3-1
- Record CO₂: On
- Record Relative Humidity: On
- Record Temperature: On
- Record Toxic Gas: Off
- Record Analog Input: Off

Chapter 3: Quick Tutorial

This quick tutorial provides step by step instructions that will take you through the basic operating procedures and give you a general understanding of how the IAQ Monitor is used.

If you have used the IAQ Monitor before, or if you are comfortable using instrumentation, this will probably give you the information you need to get started. Refer to the remainder of this reference manual for detailed instructions.

This tutorial is very straightforward and will be easy to follow even if you have never used the IAQ Monitor and are not familiar with technical instrumentation. It will help get you acquainted with the operating procedures you will be using.

NOTE: The CO₂, temperature and relative humidity sensors are built into the IAQ Monitor . See "Connecting and Calibrating Your Sensors" in Chapter 4 for information on connecting the toxic gas and linear sensors.

Turning the IAQ Monitor On and Off

1. Press the ON/OFF button. The IAQ Monitor will turn on and automatically begin displaying the present readings.
2. Press the ON/OFF button again. The IAQ Monitor will turn off.

NOTE: In order to turn off the IAQ Monitor it CANNOT be recording.

Calibrating the CO₂ Sensor

1. Unscrew and remove the toxic sensor cap (see the IAQ Monitor instrument diagram in the beginning of Chapter 4).
2. Slide the calibration adapter over the wand until the "O" ring in the bottom of the adapter slides over the handle of the wand.
3. Turn the IAQ Monitor on. It will display the present readings.
4. Wait for the sensors to stabilize (when the readings level off, the sensor is stabilized)

Calibrating the CO₂ Sensor (Continued)

- Using the supplied tubing, connect a source of Nitrogen (N₂) to the CO₂ inlet fitting of the Calibration Adapter.
- Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display:

Press Record for Programming Menu

- Press the RECORD button. The IAQ Monitor will display:

Programming Menu Clear Data

- Press the UP ARROW button repeatedly until the IAQ Monitor displays:

Programming Menu CO₂ Zero Cal

- Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the CO₂ zero calibration menu.
- Let the readings stabilize (about 5 minutes) and then press the RECORD button again. The zero CO₂ calibration value is saved.
- Press the ON/OFF button. The IAQ Monitor displays:

Programming Menu Clear Data

- Turn the regulator off. Remove the N₂ bottle from the regulator and replace it with the appropriate span gas.
- Press the UP ARROW button repeatedly until the IAQ Monitor displays:

Programming Menu CO₂ Span Cal

- Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the span calibration menu.
- Use the UP and DOWN ARROW buttons to set the cal point to the value on the bottle of span gas.

Calibrating the CO₂ Sensor (Continued)

16. Let the readings stabilize (about 5 minutes) and then press the RECORD button again. The CO₂ span calibration value is saved.
17. Press the ON/OFF button 2 times to return to the present readings screen. Turn off the valve on the regulator and disconnect the span gas.

NOTE: See "Connecting and Calibrating your Sensors" in Chapter 4 for more details on calibration.

NOTE: The regulators used for calibration must have a flow rate of 1 liter per minute.

Viewing Information with the IAQ Monitor

Turn the IAQ Monitor on and then press and release the UP ARROW button repeatedly to scroll through each of the following, one screen at a time:

- Programming Menu Screen
- Recorded Data (if applicable)
- Recording Status, Memory Left, Elapsed Recording Time
- Battery Status, Present Date and Time, Test #
- Toxic Gas and Analog Channels (if enabled)
- Main Menu (present readings on CO₂, Temperature and Humidity channels)

Start and Stop Recording

1. Turn the IAQ Monitor on and wait for the readings to stabilize (about 2 minutes).
2. Press and release the RECORD button. The IAQ Monitor will begin recording (the IAQ Monitor may display "standby" with a count down before recording begins). The IAQ Monitor will display "Recording" to indicate logging is in progress, followed by present readings on each active channel.
3. To stop recording, press the RECORD button again.

NOTE: If using Survey Mode, when the RECORD button is pressed, the IAQ Monitor will record one sample, display "Data Sample Complete" and then stop recording.

NOTE: If the CO₂ sensor has not had a chance to settle, when the RECORD button is pressed, the message "Standby" will appear to indicate that the sensor is still in a settling period. The sensor will usually settle about 2 minutes after the IAQ Monitor is turned on.

NOTE: The count down time before recording begins is dependent upon the programmed storage period (see the on-line help in ms-5000W Metrosoft for more information).

Output Reports

After recording is completed, follow these steps:

1. Connect the IAQ Monitor to a serial printer with the RS-232 cable
2. Turn on the IAQ Monitor. It will display the present readings.
3. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display:

Press Record for Programming Menu

4. Press the RECORD button. The IAQ Monitor will display:

Programming Menu Clear Data

5. Press the UP ARROW button repeatedly until the IAQ Monitor displays:

Programming Menu Print

6. Press the RECORD button. The IAQ Monitor will display:

Print Summary Report Test 01

7. Press the RECORD button. The report will be printed.
8. Press The ON/OFF button 2 times to return to the Main Screen (present readings).

Clearing Data From the IAQ Monitor

1. Turn the IAQ Monitor on. It will display the present readings.
2. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display:

Press Record for Programming Menu

3. Press the RECORD button. The IAQ Monitor will display:

Programming Menu Clear Data

4. Press the RECORD button. The IAQ Monitor will display:

Press Record to Clear Data

5. Press the RECORD button again. Data will be cleared and the IAQ Monitor will display:

Data Cleared

6. Press the ON/OFF button to return to the Main Screen.

Chapter 4: Detailed Operating Instructions


These instructions assume that you have reviewed Chapter 2 ("Getting Started") in this manual. If you have not yet reviewed Chapter 2 you should do so at this time.

Remember, all programming choices, such as which channels to record, instrument mode (datalogging or survey) temperature scale, etc., are selected using ms-5000W Metrosoft (see the on-line help in ms-5000W Metrosoft for details on setting up the IAQ Monitor for specific test applications).


Refer to the following for abbreviations used on the IAQ Monitor display:

<u>Abbreviation</u>	<u>Meaning</u>
O.R.	Out of Range (displayed when the IAQ Monitor is first turned on and the CO ₂ sensor is still settling)
deg F	Degrees Fahrenheit (displayed with reading of temperature channel)
deg C	Degrees Celsius (displayed with reading of temperature channel)
%	Percent Relative Humidity (displayed with reading of humidity channel)
ppm	Parts Per Million (displayed with reading of CO ₂ and toxic gas channels)
V	Volts Direct Current (displayed with IAQ Monitor internal battery voltage status)

Refer to the following instrument diagram when operating the IAQ Monitor:



Refer to the following instrument diagram when operating the aq-5001 IAQ Monitor:



To mount the wand on the aq-5001 for use as a portable IAQ Monitor:

1. Remove the rubber hole plug from the side of the case (the cord will retain it)
2. Lay the case flat and open the cover.
3. Lift the aq-5000 from its nesting location and slide it out of the way (disconnect cables if necessary). Feed the wand through the hole, stopping at the coil.

4. Take the wand cover out of the case, replace the aq-5000 back into its original position (reconnect cables if necessary), close the case and stand it on end as shown.
5. Align the wand pins with the 2 holes in the case and push to connect the wand to the case.
6. Insert the 2 slots in the wand cover under the case lip and tighten the thumbscrew so the wand is secure. NOTE: It is ok for the hole plug to be pinched between the wand cover and the case.
7. Hang the hole plug over the thumbscrew.

To use the aq-5001 as a hand-held IAQ Monitor, simply disconnect the cables and remove it from the case.

Turning the IAQ Monitor On and Off

To turn the IAQ Monitor on and off:

1. Press the ON/OFF button. The IAQ Monitor will turn on and display the Main Screen.

The Main Screen shows present readings of the CO₂, temperature and relative humidity channels with the recording status (recording or not recording). This screen is displayed in the following format:

NOT RECORDING	
CO2	800 PPM
R.H.	48.9 %
TEMP	75.9 degF

NOTE: The Main Screen is always displayed, even if you are not recording on one or more of these channels.

2. Press the ON/OFF button again. The IAQ Monitor will turn off.

IMPORTANT: The IAQ Monitor cannot be turned off while it is recording. If you press the On/Off button while recording is in progress, the following message will be displayed:

CANNOT TURNOFF WHILE RECORDING

This is to prevent you from accidentally interrupting a test. See "Start and Stop Recording" later in this chapter for details on how to stop recording.

If you have not yet used ms-5000W Metrosoft to program the IAQ Monitor, you will see the following message when the IAQ Monitor is turned on:

TIME AND DATE NOT PROGRAMMED

This indicates that the real time clock has not been set with the correct time, and all data recorded will be incorrectly time stamped.

The current date and time is automatically set from your computer's clock when programming the IAQ Monitor with ms-5000W Metrosoft (see the on-line help in ms-5000W Metrosoft for more details).

Connecting and Calibrating Sensors

Before you begin displaying and recording data, you should calibrate your CO₂ sensor to assure accurate readings. In addition, using an optional toxic gas sensor and/or a linear output sensor with the IAQ Monitor requires proper connection and calibration.

CO₂, Temperature and Humidity Sensors

The CO₂, temperature and humidity sensors are built into the wand of the IAQ Monitor and cannot be removed.

The CO₂ sensor is an infrared sensor that requires air to be drawn through it to produce a quick and accurate measurement of the level of CO₂ in the air. The IAQ Monitor's built in sample pump assures that air is drawn across the sensors. The CO₂ sensor should be calibrated regularly to assure accurate readings.

The humidity sensor incorporates a capacitive sensor with a monolithic CMOS circuit for a high reliability linear response. The temperature sensor is a bead type thermistor with a fast response to ambient temperatures. Both the temperature and humidity sensors are calibrated at Metrosonics factory and cannot be calibrated in the field. We recommend you return the IAQ Monitor to Metrosonics factory for yearly calibration.

Calibrating the CO₂ Sensor

Calibrating the CO₂ sensor requires calibration gas, a regulator (with a 1 liter per minute flow rate) and tubing.

We recommend using nitrogen (N₂) gas for the zero calibration.

IMPORTANT: Since the range of the CO₂ sensor is programmed using Metrosoft (0-5,000 ppm or 0-20,000 ppm), care must be taken when choosing a span calibration gas. The span calibration gas should be a sizable fraction of the selected full scale range. If the span calibration is performed using a low concentration span gas (i.e. 1,000 ppm), and then the CO₂ sensor is exposed to a large concentration of CO₂ (i.e. 15,000 ppm), the CO₂ readings displayed may exceed the accuracy specification.

We recommend using span calibration gases as follows:

<u>Programmed CO₂ Sensor Range</u>	<u>CO₂ Span Gas Concentration Recommended</u>
0 to 5,000 ppm	1,000 or 5,000 ppm CO ₂
0 to 20,000 ppm	at least 15,000 ppm CO ₂

See the on-line help in ms-5000W Metrosoft for information on selecting the desired range for the CO₂ sensor.

Follow these steps to calibrate the CO₂ sensor:

1. Unscrew and remove the toxic sensor cap (see the IAQ Monitor instrument diagram in the beginning of Chapter 4).
2. Slide the calibration adapter over the wand until the "O" ring in the bottom of the adapter slides over the handle of the wand.
3. Turn the IAQ Monitor on. It will display the present readings.
4. Wait for the sensors to stabilize (when the readings level off, the sensor is stabilized)
5. Using the supplied tubing, connect a source of Nitrogen (N₂) to the CO₂ inlet fitting of the Calibration Adapter.
6. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display the following screen:

PRESS RECORD FOR
PROGRAMMING MENU

7. Press the RECORD button. The IAQ Monitor will display the following screen:

PROGRAMMING MENU
CLEAR DATA

-
8. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:

PROGRAMMING MENU
CO2 ZERO CAL

9. Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the CO₂ zero calibration screen, which will be in the following format.

ZERO CALIBRATION
CAL POINT 0 ppm
CO2 0 ppm

The CAL POINT value is the concentration of the gas being applied, in this case Nitrogen, which is 0 ppm. The CO₂ value is the level the CO₂ sensor is detecting from the zero gas.

10. Let the readings stabilize (about 5 minutes) and then press the RECORD button. A 15 second countdown timer will be displayed while the zero calibration is performed.

Continue to watch the readings. If the CO₂ value does not stay at 0 ppm, press the RECORD button again to zero the sensor again. If necessary, this can be repeated until the CO₂ reading is consistently on 0 ppm.

11. Press the ON/OFF button. The IAQ Monitor will display the following screen:

PROGRAMMING MENU
CLEAR DATA


12. Turn the regulator off. Remove the N₂ bottle from the regulator and replace it with the appropriate CO₂ span gas.

13. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:



```
PROGRAMMING MENU
CO2 SPAN CAL
```

14. Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the span calibration screen, which will be in the following format.




```
SPAN CALIBRATION
CAL POINT  5000 ppm
CO2        5000 ppm
```

The CAL POINT value is the concentration of the CO₂ span gas being applied. The CO₂ value is the level the CO₂ sensor is detecting from the span gas.

15. If necessary, press the UP and DOWN ARROW buttons to adjust the cal point to the value on the bottle of span gas.
16. Let the readings stabilize (about 5 minutes) and then press the RECORD button. A 15 second countdown timer will be displayed while the span calibration is performed.

Continue to watch the readings. If the CO₂ value does not stay at the span gas concentration level, press the RECORD button again to span the sensor again. If necessary, this can be repeated until the CO₂ reading is consistently at the correct value.

17. Press the ON/OFF button. The IAQ Monitor will display the following screen:



```
PROGRAMMING MENU
CLEAR DATA
```

18. Press the ON/Off button to return to the Main Screen. Turn off the valve on the regulator and disconnect the span gas.

NOTE: The regulators used for calibration must have a flow rate of 1 liter per minute.

Toxic Gas Sensors

The gas channel will accept any of Metrosonics se-4000 series toxic gas sensors. We currently offer sensors for ten different gas types:

1. Carbon Monoxide (CO)
2. Hydrogen Sulfide (H₂S)
3. Sulfur Dioxide (SO₂)
4. Chlorine (Cl₂)
5. Nitrogen Dioxide (NO₂)
6. Nitric Oxide (NO)
7. Hydrogen Cyanide (HCN)
8. Ammonia (NH₃)
9. Oxygen (O₂)
10. Ethylene Oxide (ETO)

These sensors are based on well established electrochemical sensor technology. They are designed to be maintenance free and stable for long periods of use.

The following table illustrates the cross-sensitivity to a range of commonly encountered gases, expressed as the reading of the sensor when exposed to 100 ppm of the interfering gas at 20°C:

Gas	Sensor#	Interfering Gas									
		CO	H ₂ S	SO ₂	NO	NO ₂	H ₂	Cl ₂	HCN	C ₂ H ₄	HCl
CO	se-4010/4110	100	≈7	<10	<9	<20	<40	N/D	N/D	N/D	N/D
H ₂ S	se-4020	<2	100	≈10	≈1	≈-20	≈1	N/D	N/D	N/D	N/D
SO ₂	se-4030	4	<1	100	<1	≈-100	N/D	N/D	N/D	N/D	N/D
Cl ₂	se-4040	0	N/D	<-0.5	0	N/D	N/D	100	N/D	N/D	N/D
NO ₂	se-4050	-5	<5	<-0.5	0	100	N/D	N/D	N/D	N/D	N/D
NO	se-4060	0	N/D	≈5	100	<30	N/D	N/D	N/D	N/D	N/D
HCN	se-4070	N/D	N/D	N/D	N/D	N/D	N/D	N/D	100	N/D	N/D
NH ₃	se-4080	0	≈100	≈60	≈20	<10	0	≈-50	≈5	N/D	<10
ETO	se-4120	N/D	N/D	N/D	N/D	N/D	N/D	N/D	N/D	N/D	N/D

NOTE: All sensors show no response to either CH₄ or CO₂. N/D = No data available yet.

Power is automatically applied to toxic gas sensors when they are connected to the IAQ Monitor and the IAQ Monitor is turned on. After initial turn on, the IAQ Monitor will identify that a biased sensor is connected. You can then turn off the IAQ Monitor and it will continue to power the sensor to maintain the bias. When power is first applied, the sensor will take a few minutes to stabilize. Biased sensors should remain powered at all times.

Biased Sensors

NO, NH₃ and ETO are biased sensors. It is recommended that the bias be maintained at all times. If sensor power is not maintained, a stabilization period of at least 2 to 3 hours may be required.

The IAQ Monitor will supply power to a connected biased sensor, even when it is turned off. This maintains the sensor in a ready to use state with no stabilization period required. If a biased sensor will not be connected to the IAQ Monitor at all times, a bias box (part # bb-7400) may be purchased, which will supply power for up to 4 biased sensors. This will keep the sensor(s) in a ready to operate condition.

The amount of time it takes a biased sensor to stabilize when it is disconnected from its power source depends on the length of time it is unpowered. If the sensor is removed for several minutes, it may take 20 minutes or longer for the sensor to stabilize.

To use a biased sensor that has been powered with the bias box, disconnect the sensor from the bias box and immediately connect the sensor to the IAQ Monitor and turn on the IAQ Monitor. The sensor should stabilize in a few minutes.

IMPORTANT: You must turn on the IAQ Monitor after connecting a biased sensor or sensor power will not be maintained. After initial turn on, the IAQ Monitor can be turned off and the bias will still be maintained.

IMPORTANT: You must use ms-5000W Metrosoft to program the IAQ Monitor to display and record on the gas channel (see the on-line help in ms-5000W Metrosoft for details).

Connecting a Gas Sensor

Follow these steps to connect a gas sensor to the IAQ Monitor:

1. With the IAQ Monitor turned off, unscrew and remove the toxic sensor cap from the wand (see the instrument diagram at the beginning of this chapter).
2. Once the sensor cap is removed, you will see a circuit board with a white outline. Line up the outline of the gas sensor with the white outline on the circuit board.
3. Push the sensor's pins into the socket pins of the circuit board until fully seated.
4. Replace the toxic sensor cap, turning it until it is securely attached.
5. Turn on the IAQ Monitor so the sensor can be identified.

To remove the sensor, turn the IAQ Monitor off, unscrew the toxic sensor cap, and then pull the sensor straight out.

Calibrating A Gas Sensor

For best results we recommend calibration on a regular basis. Items necessary for proper calibration are the cl-5000 calibration adaptor, the appropriate calibration gas for the sensor and a 1liter-per-minute flow regulator(Part#sg-reg-1).

You will need to perform **BOTH** the zero and the span adjustment procedures to properly calibrate your sensor.

IMPORTANT: The zero and span adjustment procedures for oxygen are different than those for toxic gases. Be sure to follow the correct procedure for the sensor you are using.

The zero and span adjustments are performed electronically with the results stored in memory.

NOTE: Due to the presence of toxic gas during the calibration process, appropriate safety procedures should be followed.

NOTE: Calibration must be performed in an area known not to contain hazardous or interfering gases if ambient air will be used as the zero gas for this operation. If this is not possible, pure bottled air (we recommend Nitrogen) should be substituted. Instructions for both procedures are provided below. You only need to perform one or the other.

The quality of the calibration process depends upon the accuracy of the calibration gas and allowing the sensors to stabilize before saving the zero and span calibrations.

Refer to the instrument diagram at the beginning of this chapter.

Preparing for Calibration

To begin calibration follow these steps:

1. Connect the sensor to the IAQ Monitor and turn on the IAQ Monitor. It will display the Main Screen.
2. Allow the sensor to stabilize before beginning calibration. Stabilizing should take 30 to 60 seconds (2 to 3 hours for the NO, NH₃ and ETO sensors if the bias has not been maintained).
3. Continue on to either the toxic gas or oxygen zero and span adjustment procedures.

Toxic Gas Zero Adjustment - in an Area Free of Toxic Gases:

To perform zero adjustment in an area free of toxic gases, follow these steps:

1. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display the following screen:



PRESS RECORD FOR
PROGRAMMING MENU

2. Press the RECORD button. The IAQ Monitor will display the following screen:

```
PROGRAMMING MENU
CLEAR DATA
```

3. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:

```
PROGRAMMING MENU
TOXIC ZERO CAL
```

4. Press the RECORD button. The IAQ Monitor will display the zero calibration screen, which will be in the following format.

```
ZERO CALIBRATION

CAL POINT      0 ppm
CO              0 ppm
```

The CAL POINT value is the level the gas sensor will be calibrated to, which is always 0 ppm for a zero calibration. The gas value (this is CO in the above example) is the level the gas sensor is detecting.

5. Press the RECORD button. A 15 second countdown timer will be displayed while the zero calibration is performed.

Continue to watch the readings. If the gas value does not stay at 0 ppm, press the RECORD button again to zero the sensor again. If necessary, this can be repeated until the gas sensor reading is consistently on 0 ppm.

6. Continue on to the span adjustment procedure.

NOTE: The calibration adaptor should NOT be on the sensor during this procedure.

Toxic Gas Zero Adjustment - Using a Cylinder of Pure Air

To perform zero adjustment using a cylinder of pure air follow these steps:


NOTE: Use a 1 liter per minute flow rate regulator when calibrating.

1. Unscrew and remove the toxic sensor cap (see the IAQ Monitor instrument diagram in the beginning of this Chapter).
2. Slide the calibration adapter over the wand until the "O" ring in the bottom of the adapter slides over the handle of the wand.
3. Using the supplied tubing, connect a source of pure air (we recommend Nitrogen) to the toxic gas inlet fitting of the calibration adapter.
4. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display the following screen:




PRESS RECORD FOR
PROGRAMMING MENU

5. Press the RECORD button. The IAQ Monitor will display the following screen:



PROGRAMMING MENU
CLEAR DATA

6. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:



PROGRAMMING MENU
TOXIC ZERO CAL

7. Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the toxic gas zero calibration screen, which will be in the following format:

ZERO CALIBRATION	
CAL POINT	0 ppm
CO	0 ppm

The CAL POINT value is the level the gas sensor will be calibrated to, which is always 0 ppm for a zero calibration. The gas value (this is CO in the above example) is the level the gas sensor is detecting from the zero gas.

8. Let the readings stabilize (about 5 minutes) and then press the RECORD button. A 15 second countdown timer will be displayed while the zero calibration is performed.

Continue to watch the readings. If the gas value does not stay at 0 ppm, press the RECORD button again to zero the sensor again. If necessary, this can be repeated until the gas sensor reading is consistently on 0 ppm.

9. Press the ON/OFF button. The IAQ Monitor will display the following screen:

PROGRAMMING MENU
CLEAR DATA

10. Turn the regulator off. Remove the bottle of pure air from the regulator and replace it with the appropriate span gas.
11. Continue on to the span adjustment procedure.

NOTE: Always remove the regulator from the gas cylinder when the procedure is complete.

Toxic Gas Span Adjustment

To perform the span adjustment procedure, follow these steps:

NOTE: Use a 1 liter per minute flow rate regulator when calibrating.

1. Unscrew and remove the toxic sensor cap (see the IAQ Monitor instrument diagram in the beginning of this Chapter).
2. Slide the calibration adapter over the wand until the "O" ring in the bottom of the adapter slides over the handle of the wand.
3. Using the supplied tubing, connect the span gas to the toxic gas inlet fitting of the calibration adapter.
4. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display the following screen:



PRESS RECORD FOR
PROGRAMMING MENU

5. Press the RECORD button. The IAQ Monitor will display the following screen:



PROGRAMMING MENU
CLEAR DATA

6. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:



PROGRAMMING MENU
TOXIC SPAN CAL

7. Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the toxic gas span calibration screen, which will be in the following format:

SPAN CALIBRATION	
CAL POINT	200 ppm
CO	200 ppm

The CAL POINT value is the concentration of the span gas. The gas value (this is CO in the above example) is the level the gas sensor is detecting from the span gas.

8. Press the UP and DOWN ARROW buttons to adjust the cal point to the value on the bottle of span gas.
9. Let the readings stabilize (about 5 minutes) and then press the RECORD button. A 15 second countdown timer will be displayed while the span calibration is performed.

Continue to watch the readings. If the gas value does not stay at the span gas concentration level, press the RECORD button again to span the sensor again. If necessary, this can be repeated until the gas sensor reading is consistently at the correct value.

10. Press the ON/OFF button. The IAQ Monitor will display the following screen:

PROGRAMMING MENU
CLEAR DATA

11. Turn the regulator off and remove the bottle of span gas from the regulator.
12. Press the ON/OFF button. The IAQ Monitor will display the following screen:

PROGRAMMING MENU
CLEAR DATA

13. Press the ON/Off button to return to the Main Screen.

NOTE: Always remove the regulator from the gas cylinder when the calibration procedure is complete.

Oxygen Zero Adjustment

Performing a zero calibration on the oxygen sensor requires a cylinder of pure nitrogen, tubing, and a regulator with a 1 liter per minute flow rate.

Follow these steps to perform a zero adjustment on the oxygen sensor:

NOTE: Use a 1 liter per minute flow rate regulator when calibrating.

1. Unscrew and remove the toxic sensor cap (see the IAQ Monitor instrument diagram in the beginning of this Chapter).
2. Slide the calibration adapter over the wand until the "O" ring in the bottom of the adapter slides over the handle of the wand.
3. Using the supplied tubing, connect the bottle of pure nitrogen to the toxic gas inlet fitting of the calibration adapter.
4. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display the following screen:




PRESS RECORD FOR
PROGRAMMING MENU

5. Press the RECORD button. The IAQ Monitor will display the following screen:



PROGRAMMING MENU
CLEAR DATA

6. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:



PROGRAMMING MENU
TOXIC ZERO CAL

7. Open the valve on the regulator and then press the RECORD button. The IAQ Monitor will display the toxic gas zero calibration screen, which will be in the following format.

ZERO CALIBRATION	
CAL POINT	0.0 %
O2	0.0 %

The CAL POINT value is the concentration of the pure nitrogen gas, which is 0.0%. The O2 value is the level the oxygen sensor is detecting from the nitrogen gas.

8. Let the readings stabilize (about 5 minutes) and then press the RECORD button. A 15 second countdown timer will be displayed while the zero calibration is performed.

Continue to watch the readings. If the O₂ value does not stay at 0.0%, press the RECORD button again to zero the sensor again. If necessary, this can be repeated until the O₂ sensor reading is consistently at 0.0%.

9. Press the ON/OFF button. The IAQ Monitor will display the following screen:

PROGRAMMING MENU
CLEAR DATA

10. Turn the regulator off and remove the bottle of nitrogen from the regulator.
11. Continue with the oxygen span adjustment.

The quality of the calibration process depends upon the accuracy of the calibration gas and allowing the sensor to stabilize before saving the zero and span calibrations.

NOTE: Always remove the regulator from the gas cylinder when the procedure is complete.

Oxygen Span Adjustment

Follow these steps to perform an oxygen span adjustment.


NOTE: The oxygen span adjustment must be done in an area free of toxic gases. If an area free of toxic gases is not accessible, a bottle with a known concentration of oxygen can be used to span adjust the oxygen sensor in place of the procedure described below.

1. Press the UP ARROW button (press the UP ARROW button one more time if the backlight was off). The IAQ Monitor will display the following screen:



PRESS RECORD FOR
PROGRAMMING MENU

2. Press the RECORD button. The IAQ Monitor will display the following screen:




PROGRAMMING MENU
CLEAR DATA

3. Press the UP ARROW button repeatedly until the IAQ Monitor displays the following screen:



PROGRAMMING MENU
TOXIC SPAN CAL

4. Press the RECORD button. The IAQ Monitor will display the span calibration screen, which will be in the following format.



SPAN CALIBRATION


CAL POINT	20.9%
O2	20.9%

The CAL POINT value is the level the oxygen sensor will be calibrated to, which should always be 20.9% for an oxygen span calibration in room air. The O2 value is the level the oxygen sensor is detecting.

5. If necessary, press the UP and DOWN ARROW buttons to adjust the cal point to 20.9%. If using a bottle of oxygen, adjust the cal point to the value on the bottle for performing the span adjustment.
6. Press the RECORD button. A 15 second countdown timer will be displayed while the span calibration is performed.

Continue to watch the readings. If the O₂ value does not stay at 20.9%, press the RECORD button again to span the sensor again. If necessary, this can be repeated until the O₂ sensor reading is consistently on 20.9%.

7. Press the ON/OFF button. The IAQ Monitor will display the following screen:



8. Press the ON/OFF button to return to the Main Screen.

NOTE: The calibration adaptor should NOT be on the sensor during this procedure.


Linear Input Sensor

The linear input channel is for general purpose datalogging. It is compatible with nearly any sensor with a voltage output that is linear with the signal input. This channel is a non-isolated, single-ended input which accepts bipolar signals up to 1 volt.

You must use ms-5000W Metrosoft to program the IAQ Monitor to display and record on this channel, specify type of units being measured, description, and calibration points (see the on-line help in ms-5000W Metrosoft for details).

The input connector for the linear input channel is designated as follows:

- pin
- 1 Signal High
 - 2 Signal Low
 - 3 Cold Start
 - 4 Common



Connecting your linear input sensor requires one of Metrosonics optional adapters (see "Accessories" in chapter 5). To connect your linear input sensor, simply plug it into the connector labeled Analog Input. This connector is located on the top end cap of the IAQ Monitor.

NOTE: Connecting pin 3 to either pin 2 or pin 4 will result in the IAQ Monitor losing all programming and loss of stored data.

Helpful Hints for Calibrating Sensors

After calibration, once the sensor stabilizes, if the sensor does not read zero in an area free of toxic gases or when exposed to a cylinder of pure air, the zero and span calibration procedures should be repeated.

Viewing Information with the IAQ Monitor

You can view various information on the IAQ Monitor's display. To scroll through the different screens, follow these steps:

1. Turn the IAQ Monitor on. It will display the Main Screen, which shows present readings of the CO₂, temperature and relative humidity channels with the recording status (recording or not recording). This screen is displayed in the following format:

NOT RECORDING	
CO2	800 PPM
R.H.	48.9 %
TEMP	75.9 degF

NOTE: The Main Screen is always displayed, even if you are not recording on one or more of these channels.

2. Press the UP ARROW button. The IAQ Monitor will scroll to the following screen, which gives you access to the programming menu:

PRESS RECORD FOR PROGRAMMING MENU

3. If data has not yet been recorded, skip to step 5.

If data has been recorded, press the UP ARROW button. The IAQ Monitor will scroll to the next screen, which shows the results of the recorded data with the number of the test being viewed. Only channels that were recorded are included in this screen. This screen will be in the following format:

CO2	R.H.	TEMP
2522	31.6	79.6
CO	ANLG	TEST
3.1	1.000	1

If using survey mode, the data will be the last (most recent) sample recorded. If using datalogging mode, that data will be the overall statistics.

NOTE: This screen will be skipped if data has not been recorded.

4. Continue to press the UP ARROW button to scroll through the results for each test in memory.

NOTE: These screens will be skipped if data has not been recorded, or if only 1 test has been recorded.

5. Press the UP ARROW button. The IAQ Monitor will scroll to the next screen, which shows the recording status, amount of memory remaining and elapsed recording time. This screen is displayed in the following format:

```
NOT RECORDING
MEMORY LEFT:  80%
ELAPSED TIME:
0 DAYS 02:11:06
```

6. Press the UP ARROW button. The IAQ Monitor will scroll to the next screen, which shows the recording status, battery status, present date and time and test #. This screen is displayed in the following format:

```
NOT RECORDING
BATTERY  4.7v (OK)
OCT 09   12:49:27
TEST NUMBER 1
```

7. If you do not have the toxic sensor installed and/or linear input channel turned on, skip to step 8.

If you do have the toxic sensor installed and/or linear input channel turned on, press the UP ARROW button. The IAQ Monitor will scroll to the next screen, which shows the present readings on the toxic and/or linear input channel with the recording status. This screen is displayed in the following format:

```
NOT RECORDING
CO       3.3 ppm
ANLG    1.0001pm
```

NOTE: This screen will be skipped if the toxic and/or linear channels are not in use.

8. Press the UP ARROW button. The IAQ Monitor will return to the Main Screen. If desired, continue to press the UP ARROW button to scroll through the screens again.

NOTE: If desired you can use the DOWN ARROW button to scroll through the screens in reverse order.

Start and Stop Recording

Follow these steps to start and stop recording:

1. Turn the IAQ Monitor on. The unit will display the Main Screen.
2. Press the Record button.

If using survey mode, the IAQ Monitor will record one sample, display the message "DATA SAMPLE COMPLETE" and then automatically stop recording.

If using datalogging mode, the IAQ Monitor will begin recording. It will continue to display present readings and the recording status will change to "RECORDING". The IAQ Monitor may display "standby" followed by a countdown time before recording begins. This depends on the storage period programmed. If the IAQ Monitor is programmed with a 10 minute storage period, it will standby until the beginning of the next 10 minute interval to start recording.

NOTE: If the CO₂ sensor has not had a chance to settle, when the RECORD button is pressed, the message "Standby" will appear to indicate that the sensor is still in a settling period. The sensor will usually settle about 2 minutes after the IAQ Monitor has been turned on.

3. Press the Record button again to stop recording. The IAQ Monitor will stop recording and the recording status will return to NOT RECORDING.
4. If desired, press the Record button again to begin another test.

NOTE: You may start and stop recording up to 64 times.

NOTE: Each time a recording session is started a new incremental test number is automatically assigned to the data.

NOTE: See the on-line help in ms-5000W Metrosoft for information on selecting how you want to record data.

Outputting Reports Directly To A Printer

You can output a summary report of your recorded data directly from the IAQ Monitor to a serial printer.

To output a report follow these steps:

1. Record your test data and stop recording.
2. Connect the IAQ Monitor to a serial printer with the RS-232 cable and turn on the IAQ Monitor. It will display the Main Screen,
3. Press the UP ARROW button and the following screen will be displayed:




PRESS RECORD FOR
PROGRAMMING MENU

4. Press the RECORD button and the following screen will be displayed:




PROGRAMMING MENU
CLEAR DATA

5. Press the UP ARROW button repeatedly until the following screen is displayed:




PROGRAMMING MENU
PRINT

6. Press the RECORD button and the following screen will be displayed, with the most recently recorded test selected:



PRINT SUMMARY REPORT
TEST 01

7. If more than one test has been recorded, press the UP and DOWN ARROW buttons to scroll through the test numbers and select the test you want to print.
8. Press the RECORD button. The IAQ Monitor will print the report and display the following message:



PRINTING...

9. When printing is complete, press the ON/OFF button 2 times to return to the Main Screen.

NOTE: The serial printer must be set for the same baud rate as the IAQ Monitor (factory default is 9600 baud).

Clearing Data From the IAQ Monitor


To erase all recorded test data from the IAQ Monitor:

1. Turn the IAQ Monitor on. It will display the Main Screen.
2. Press the UP ARROW button and the following screen will be displayed:



PRESS RECORD FOR
PROGRAMMING MENU

3. Press the RECORD button and the following screen will be displayed:




PROGRAMMING MENU
CLEAR DATA

4. Press the RECORD button and the following screen will be displayed:




PRESS RECORD TO
CLEAR DATA

5. Press the RECORD button again. The following message will be displayed while the data is cleared:



DATA CLEARED

Once the data is cleared, the IAQ Monitor will return to the following screen:



PROGRAMMING MENU
CLEAR DATA

6. Press the ON/OFF button to return to the Main Screen.

NOTE: Data can also be cleared using ms-5000W Metrosoft (see the on-line help in ms-5000W Metrosoft for details).

Secure Mode

The Secure Mode feature is used to prevent tampering and unauthorized use.

If Secure Mode is enabled while the IAQ Monitor is recording, all functions will be locked out until Secure Mode is disabled.

If Secure Mode is enabled while the IAQ Monitor is not recording, you will be able to turn the IAQ Monitor on and off, but all other functions will remain locked out until Secure Mode is disabled.

Secure Mode is enabled and disabled by entering the correct 4-digit Secure Code, in the correct sequence. The Secure Code is selected when programming the IAQ Monitor with Metrosoft (see the on-line help in ms-5000W Metrosoft for details).

To use Secure Mode:

1. Turn the IAQ Monitor on. It will display the Main Screen.
2. Press the UP ARROW button and the following screen will be displayed:




PRESS RECORD FOR
PROGRAMMING MENU

3. Press the RECORD button and the following screen will be displayed:




PROGRAMMING MENU
CLEAR DATA

4. Press the UP ARROW button repeatedly until the following screen is displayed:



PROGRAMMING MENU
SECURE MODE

5. Press the RECORD button and the following screen will be displayed:



ENTER SECURE CODE


6. Enter the 4-digit Secure Code by pressing the buttons on the keypad. The buttons on the IAQ Monitor's keypad are assigned a corresponding number as indicated below:

<u>Button</u>	<u>Corresponding Number</u>
ON/OFF	Not Used
RECORD	1
UP ARROW	2
DOWN ARROW	3

For example, if the Secure Code is 1-2-3-1, you would press RECORD - UP ARROW - DOWN ARROW - RECORD.

The Secure Code must be entered in the exact sequence.

Once the correct Secure Code is entered, the IAQ Monitor will display the following screen to indicate that Secure Mode is been enabled:



IAQ Monitor IS SECURED
ENTER CODE TO EXIT

7. To exit Secure Mode, enter the 4-digit Secure Code again. If the correct code is entered, Secure Mode will be disabled and the IAQ Monitor will display the Main Screen.

Chapter 5: Specifications & Accessories

Specifications

INPUTS:

Carbon Dioxide:

Detector: NDIR (non-dispersive infrared)

Range: 0 to 5000 or 0 to 20,000 ppm (user-selectable)

Accuracy:

0 to 5000 ppm range: $\pm 3\%$ of reading ± 50 ppm

0 to 20,000 ppm range: $\pm 3\%$ of reading ± 300 ppm

Temperature Influence: additional $\pm 0.2\%$ of reading ± 2 ppm for each deg C

Resolution: 1 ppm (10 ppm above 10,000 ppm)

Response Time: 22 seconds for 63% of final value; 70 seconds for 10-90% of 4000 ppm change

Relative Humidity:

Detector: Capacitive

Range: 0 to 100% non-condensing

Accuracy: $\pm 3\%$ @ 25°C

Resolution: 0.1%

Response Time: 50 seconds with minimum air flow of 1 mi/hr through wand

Temperature:

Detector: Thermistor

Range: 0° to +60°C (+32° to +140°F)

Accuracy: $\pm 0.5^\circ\text{C}$ ($\pm 0.9^\circ\text{F}$) - requires minimum air flow of 1 mi/hr through wand

Resolution: 0.1° C or F

Linear Channel:

Linear DC Voltage Range: ± 1 Vdc

Accuracy: $\pm 2\%$ of full scale

Resolution: 0.001 Vdc

Toxic Gas Channel:

Display Resolution: 0.1, 0.5 or 1 ppm, depending on sensor type

Full Scale:	Gas Type	FS	Repeatability
	Carbon Monoxide (CO)	1000 ppm	3% ± 2 LSD
	Hydrogen Sulfide (H ₂ S)	300 ppm	3% ± 2 LSD
	Sulfur Dioxide (SO ₂)	100 ppm	3% ± 2 LSD
	Chlorine (Cl ₂)	20 ppm	3% ± 2 LSD
	Nitrogen Dioxide (NO ₂)	20 ppm	3% ± 2 LSD
	Nitric Oxide (NO)	200 ppm	3% ± 2 LSD
	Oxygen (O ₂)	30 %	N/A
	Hydrogen Cyanide (HCN)	100 ppm	3% ± 2 LSD
	Ammonia (NH ₃)	200 ppm	10% ± 2 LSD
	Ethylene Oxide (ETO)	20 ppm	2% ± 2 LSD

NOTE:

LSD = Least Significant Digits

FSO = Full Scale Output

DATA STORAGE

Standard: 57,344 total samples

DISPLAY

Display Type: 20-character by 4-line backlit LCD

REAL TIME CLOCK

Accuracy: 0.01%

TIME HISTORY

Sample Rate: 1 second, Fixed

Storage Rate (Sampling Interval): User selectable, 1 second, 1 minute, 5 minute, 10 minute or 15 minute samples or averages

Statistics Saved: Up to 5 data values per sampling interval (CO₂, temperature, relative humidity, gas and linear input)

COMMUNICATIONS

Format: RS-232, 1 start, 8 data, 1 stop bit, no parity

Baud Rate: 1200 to 38400

PRINTER OUTPUT

Summary Report: Separate reports for each logging session indicating minimum, maximum and time of occurrence, elapsed time and average per session.

Time History Report: All recorded data values with date and time stamp.

POWER**Internal:**

Battery Type: 4 AA alkaline or rechargeable NIMH battery pack

Operational Life: Greater than 15 hours using AA alkaline batteries; 7 hours typical using optional battery pack at 25°C

Data Retention: 30 days in the event of a low battery

External: 6.0 Vdc @ 0.5 amp, supplied by AC Power Adapter

ENVIRONMENTAL

Operating: +32 to 122°F (0° to +50°C)

Storage: -4 to +140°F (-20° to +60°C)

PHYSICAL**Size:**

aq-5000:

Enclosure Size: 3.6 x 7.1 x 1.3 inches (9.1 x 18.0 x 3.3 cm)

Wand Size: 11.8 inches (30 cm), 1 inch (2.54 cm) diameter

aq-5001:

Enclosure Size: 15 x 10.5 x 6 inches (38.1 x 26.7 x 15.2 cm)

Wand Size: 11.8 inches (30 cm), 1 inch (2.54 cm) diameter

Weight:

aq-5000: 2 lbs (0.83 kg)

aq-5001: 10.7 lbs (4.8 kg)

Specifications subject to change without notice.

Accessories

Monitor Options and Accessories

<u>Part #</u>	<u>Description</u>
ba-7400	Rechargeable Nickel Metal Hydride Battery Pack
bc-7400-2	Universal AC Charger - for ba-7400 battery pack (120-240V)
bc-7400-1	AC Charger - for ba-7400 battery pack (120V)
ws-5000	Wrist Strap
ps-5000-2UA	Universal AC Power Supply - US style AC plug
ps-5000-2UE	Universal AC Power Supply - European style AC plug
ps-5000-2UB	Universal AC Power Supply - U.K. style AC plug
ca-232-01	Computer Interface Cable
cl-5000	Calibration Adapter - with 2' of tubing
mf-5000	Desktop Stand - for unattended monitoring
se-4005	Oxygen Sensor - 30%
se-4010	Carbon Monoxide Sensor - 1000 ppm
se-4020	Hydrogen Sulfide Sensor - 300 ppm
se-4030	Sulfur Dioxide Sensor - 100 ppm
se-4040	Chlorine Sensor - 20 ppm
se-4050	Nitrogen Dioxide Sensor - 50 ppm
*se-4060	Nitric Oxide Sensor - 200 ppm
se-4070	Hydrogen Cyanide Sensor - 100 ppm
*se-4080	Ammonia Sensor - 200 ppm
bb-7400	Sensor Bias Box -for powering sensors during storage. Includes ps-7400A power supply
ps-7400A	Replacement AC Adapter - for bb-7400 Bias Box
sg-CO2-1000	Calibration Gas - 1000 ppm CO ₂ / Balance Air (103 liters)
sg-CO2-5000	Calibration Gas - 5000 ppm CO ₂ / Balance Air (103 liters)
sg-N2	Calibration Gas - 100% Nitrogen (103 liters)
sg-CO-35	Calibration Gas - 35 ppm CO / Balance Air (103 liters)
sg-H2S-10	Calibration Gas - 10 ppm H ₂ S / Balance Nitrogen (58 liters)
sg-SO2-5	Calibration Gas - 5 ppm SO ₂ / Balance Air (58 liters)
sg-Cl2-2	Calibration Gas - 2 ppm Cl ₂ / Balance Nitrogen (58 liters)
sg-NO2-5	Calibration Gas - 5 ppm NO ₂ / Balance Air (58 liters)
sg-NO-25	Calibration Gas - 25 ppm NO / Balance Nitrogen (58 liters)
sg-HCN-10	Calibration Gas - 10 ppm HCN / Balance Nitrogen (58 liters)
sg-NH3-50	Calibration Gas - 50 ppm NH ₃ / Balance Nitrogen (58 liters)
sk-1000	Calibration Kit - Includes carrying case, regulator, tubing and 1000 ppm CO ₂ & N ₂ gases
sk-5000	Calibration Kit - Includes carrying case, regulator, tubing and 5000 ppm CO ₂ & N ₂ gases
sg-reg-2	Regulator - for 58 and 103 liter cylinders. 1 lpm flow rate, no gauge or valve.
sg-reg-1	Regulator - for 58 and 103 liter cylinders. 1 lpm flow rate with gauge and valve.

*Biased sensors: bb-7400 sensor bias box recommended for maintaining the sensor in a ready state when not attached to the aq-5000/5001.

Input Cables for Linear Output Sensors/Analyzers

<u>Part #</u>	<u>Description</u>
ca-500 A00	Input Cable, Bare Leads
ca-500 A01	Input Cable, Double Banana Plug
ca-500 A02	Input Cable, Mini Double Banana Plug
ca-500 A03	Input Cable, Mini Alligator Clips
ca-500 A04	Input Cable, Phone Plug (RCA)
ca-500 A05	Input Cable, Phone Plug, 1/4" Diameter
ca-500 A06	Input Cable, Mini Phone Plug, 1/8" Diameter
ca-500 A07	Input Cable, Sub-Mini Phone Plug, 1/16" Diameter
ca-500 A08	Input Cable, #6 Spade Lugs
ca-500 A09	Input Cable, Phone Plug 2.5 mm.
ca-500 B01	Input Cable, Amphenol, 126 Series, 5-Pin Connector
ca-500 B02	Input Cable, Mini Phone Plug
ca-500 B03	Input Cable, Mini Phone Plug w/Resistor
ca-500 B04	Input Cable, BNC Connector
ca-500 B05	Input Cable, Amphenol, 126 Series, 5-Pin Connector
ca-500 B06	Input Cable, 1/16" Phone-Tip Plug (2)
ca-500 B07	Input Cable, Mini Power Connector
ca-500 B08	Input Cable, Sub-mini Phone Plug
ca-500 B10	Input Cable, 5-Pin DIN Connector
ca-500 B11	Input Cable, Amphenol 5-Pin Connector
ca-500 B12	Input Cable, 4-Pin Switchcraft Connector
ca-500 B13	Input Cable, 4-Pin Vernitron Connector
ca-500 B14	Input Cable, Amphenol 5-Pin Connector
ca-500 B15	Input Cable, 5-Pin DIN Connector
ca-500 B16	Input Cable, 7-Pin Amphenol Connector
ca-500 B17	Input Cable, 8-Pin DIN Connector
ca-500 C03	Input Cable, 2-Pin Lemo Connector
ca-500 C04	Input Cable, 4-Pin F Lemo B-Series Connector
ca-500 C05	Input Cable, 4-Pin M Lemo B-Series Connector
ca-500 C06	Input Cable, 6-Pin F Armaco Connector

A

Abbreviations 15
AC Power and the Internal Battery 3–7
Accessories 51–52

B

Battery 3–7
Battery Pack 5–7
Before You Begin 3–8
 AC Power and the Internal Battery 3–7
 Default Recorder Setup 8
 Hardware Requirements 3
 Selecting Channels 7–8
 Setting the Real Time Clock 7
Biased Sensors 26

C

Calibrating the CO2 Sensor 9–11, 21–25
Clearing Data from the IAQ Monitor 13, 45–46
CO2, Temperature and Humidity Sensors 21–25
Connecting and Calibrating Sensors 21–38
 CO2, Temperature and Humidity Sensors 21–25
 Helpful Hints 38
 Linear Input Sensor 38
 Toxic Gas Sensors 25–37

D

Default Recorder Setup 8
Detailed Operating Instructions 15–48
 Clearing Data from the IAQ Monitor 45–46
 Connecting and Calibrating Sensors 21–38
 Helpful Hints 38
 Linear Input Sensor 38
 Toxic Gas Sensors 25–37
Display Abbreviations 15
Outputting Reports 43–44
Secure Mode 47–50
Start and Stop Recording 42
Turning the IAQ Monitor On and Off 19–20
Viewing Information 39–41

G

Gas Sensors 25–37
Getting Started 3–8
Getting Started with the aq-5000
 Before You Begin 3–8
 AC Power and the Internal Battery 3–7
 Default Recorder Setup 8
 Hardware Requirements 3
 Selecting Channels 7–8
 Setting the Real Time Clock 7

H

Hardware Requirements 3
Helpful Hints for Calibrating Sensors 38

L

Linear Input Sensor 38

O

Output Reports 12, 43–44

R

Real Time Clock 7
Reports 12

S

Secure Mode 47–48
Selecting Channels 7–8
Sensors 21–38
Specifications 49–50
Start and Stop Recording 11–12, 42

T

Toxic Gas Sensors 25–37
 Biased Sensors 26
Turning the IAQ Monitor On and Off 9, 19–20

Tutorial 9–13

- Calibrating the CO2 Sensor 9–11
- Clearing Data from the IAQ Monitor 13
- Output Reports 12
- Start and Stop Recording 11–12
- Turning the IAQ monitor On and Off 9
- Viewing Information 11

V

Viewing Information 11, 39–41

METROSONICS

aq Series Indoor Air Quality Monitors Manual



PO Box 23075 • Rochester, New York 14692
PART NUMBER 2099-003 REV. C

Warranty Clause

METROSONICS warrants each new product manufactured and sold to be free from defects in material, workmanship and construction, and that when used in accordance with this owner's manual will perform to applicable specifications for a period of one year after shipment.

If examination by METROSONICS discloses that the product has been defective, then our obligation is limited to repair or replacement, at our option, of the defective unit or its components.

METROSONICS is not responsible for products which have been subject to misuse, alteration, accident or for repairs not performed by METROSONICS.

The foregoing warranty constitutes METROSONICS sole liability, and is in lieu of any other warranty, of merchantability or fitness. METROSONICS shall not be responsible for any incidental or consequential damages arising from any breach of warranty.

Service Information

In the event the aq Series Indoor Air Quality Monitor appears defective, call the METROSONICS Repair Department at (716) 427-7402. The Repair Department will determine the cause of the apparent malfunction and provide the necessary support to correct the problem. In some cases, problems can be corrected over the telephone. Therefore, before returning any equipment to the factory for service, discuss all problems with the Repair Department.

Equipment Return

Prior to returning the aq Series Indoor Air Quality Monitor, obtain a Return Authorization number from the METROSONICS Repair Department (716-427-7402). Each shipment must have a packing slip which includes:

1. A Return Authorization number.
2. A list of all items enclosed with applicable serial numbers.
3. Reason for returning (e.g. malfunction, described in detail).
4. Billing and shipping address for return.

Returns must be properly packaged with transportation charges prepaid to METROSONICS; return transportation charges will be F.O.B. factory. Send returns to:

Metrosonics
285 Metro Park
Rochester, NY 14623
Attention: Repair Department

Table Of Contents

Chapter 1: Introduction	1
Chapter 2: Getting Started	3
Before You Begin	3
Check to Make Sure You have the Right Hardware	3
Using AC Power and the Internal Battery	3
Setting the Real Time Clock	7
Selecting Channels	7
Default Recorder Setup	8
Chapter 3: Quick Tutorial	9
Turning the IAQ Monitor On and Off	9
Calibrating the CO₂ Sensor	9
Viewing Information with the IAQ Monitor	11
Start and Stop Recording	11
Output Reports	12
Clearing Data from the IAQ Monitor	13
Chapter 4: Detailed Instructions	15
Turning the IAQ Monitor On and Off	19
Connecting and Calibrating Sensors	21
CO ₂ , Temperature and Humidity Sensors	21
Toxic Gas Sensors	25
Linear Input Sensor	38
Helpful Hints for Calibrating Sensors	38
Viewing Information with the IAQ Monitor	39
Start and Stop Recording	42
Outputting Reports Directly to a Printer	43
Clearing Data from the IAQ Monitor	45
Secure Mode	47
Chapter 5: Specifications & Accessories	49
Specifications	49
Accessories	51
Index	53